

Note:  
The distance shown should be used where possible. Where not possible, keep as far from the road as you can but not less than two (2) feet.

FIGURE 5. Typical Locations for Stop and Yield Signs  
See MUTCD sec. 2A - 21


### How to assemble your new post and sign

Mount your sign to the post using 3/8" bolts or rivets. Put bolt or rivet in the top hole in your new sign, then place the bolt or rivet thru the second hole down from the top of the post as shown and tighten down. Then place a bolt or rivet thru the bottom hole on the sign and tighten down.



The 18" sleeve is not used anymore

Slide the 18" sleeve over the 30" base aligning the top hole of each together, next slide both of them over the end of the post, align the top holes of the base and the sleeve with the 9th hole from the bottom of the post as shown, insert a 3/8" x 3 1/4" bolt thru holes and tighten with nut till snug. Bury post in the ground 30" deep. Installation is done!



Post 10'